

## **Quick Setup Guide**

Read the *Product Safety Guide* first, then read this *Quick Setup Guide* for the correct installation procedure.



D01U2C001-00 USA/CAN

# Not all models are available in all countries. The latest manuals are available at the Brother Solutions Center: <a href="mailto:support.brother.com/manuals">support.brother.com/manuals</a>.

# Unpack the machine and check the components



Watch our Video FAQs for

support.brother.com/videos.

help with setting up your


Brother machine:



**Brother Installation Disc** 



Toner Cartridge Replacement (For HL-L2370DWXL model) Use the toner cartridge that is pre-installed in the





Quick Setup Guide
Reference Guide (only for certain models)
Product Safety Guide

#### NOTE:

- Manuals in Spanish for this model are available on the Brother Solutions Center. (USA only): <a href="mailto:support.brother.com/manuals">support.brother.com/manuals</a>
   Los manuales en español de este modelo están disponibles en el Brother Solutions Center (Solamente en los Estados Unidos):
- el Brother Solutions Center. (Solamente en los Estados Unidos): support.brother.com/manuals
- The components included in the box may differ depending on your country.
- The available connection interfaces vary depending on the model.
- Interface cables are not included. You must purchase the correct interface cable if you require one.

#### USB cable


We recommend using a USB 2.0 cable (Type A/B) that is no more than 6 feet (2 meters) long.

#### •


**Network cable**Use a straight-through Category 5 (or greater) twisted-pair cable.

- The illustrations in this Quick Setup Guide show the HL-L2370DW.
- This machine's *Reference Guide* is either printed for you or is available on the Brother Installation Disc included in the carton.


## Remove the packing materials and install the drum unit and toner cartridge assembly



## 2 Load paper in the paper tray




## 3 Connect the power cord and turn on the machine




### Select your language (if needed)


- **1.** Press  $\nabla$  or  $\triangle$  to select [Initial Setup], and then press **OK**.
- 2. Press OK to select [Local Language].
- 3. Press ▼ or ▲ to select your language, and then press OK.





### Select a device to connect to your machine






Brother regularly updates firmware to add features and apply bug fixes. To

check for the latest firmware, visit support.brother.com/up5.

6

### Connect your computer



Put the installation disc into your CD/DVD drive, or download the Full Driver & Software Package at:

For Windows®: <a href="mailto:support.brother.com/windows">support.brother.com/windows</a>
For Mac: <a href="mailto:support.brother.com/mac">support.brother.com/mac</a>

If you are using a recently released operating system on your computer, visit the above websites for updated driver and software information. Follow the on-screen instructions and prompts.

For Windows®:

If the Brother screen does not appear automatically, go to **Computer (This PC)**. Double-click the CD/DVD-ROM icon, and then double-click **start.exe**.


Finished

For Network Users: Important Notice for Network Security

The default Web Based Management password is located on the back of the machine and marked "Pwd".

We recommend immediately changing the default password to use network tools/utilities securely and to protect your machine from unauthorized access.





Restart your wireless access point/router (if possible).

Disconnect the cable.

Restart your machine and computer, and then go to 6

If still not successful, go to 7.

Even if you do not have a wireless access point/router, you can connect your device and your machine directly. For additional wireless network support, go to

If still not successful, visit <u>support.brother.com</u> for FAQs & Troubleshooting.

7

### Alternative wireless setup

Find your SSID (Network Name) and Network Key (Password) on your wireless access point/ router and write them in the table provided below.

SSID (Network Name)

SSID: XXXXXXX
Network key: XXXX

If you cannot find this information, ask your network administrator or wireless access point/router manufacturer.

To select each menu option, press ▲ or ▼, and then press OK to confirm.

Select [Network] > [WLAN] > [Setup Wizard], and then press ▼.

Select the SSID (Network Name) for your access point/router and enter the Network Key (Password).

support.brother.com/wireless-support.

When the wireless setup is successful, the LCD displays [Connected].

If setup is not successful, restart your Brother machine and your wireless access point/router, and repeat 7.

For Computer

Go to 6 to install software.

For Mobile Device

Go to 8 to install apps.

8

### Print using your mobile device

Your mobile device must be connected to the same wireless network as your Brother machine.

Brother SupportCenter is a mobile app that provides the latest support information for your Brother product.

Visit the App Store or Google Play™ to download.







AirPrint is available for Apple device users. You do not need to download any software to use AirPrint. For more information, see the *Online User's Guide*.



Download and install the Mopria<sup>®</sup> Print Service app from Google Play<sup>™</sup> using your Android<sup>™</sup> device.



Download and install our free application **Brother iPrint&Scan** from a mobile application store, such as the App Store, Google Play™ or Microsoft® Store using your mobile device.

#### **Optional apps**

You can print from your mobile device using various apps. (USA only) For more information on apps, visit <a href="https://www.brother-usa.com/connect">www.brother-usa.com/connect</a>.

For instructions, see the *Online User's Guide*.