MFC-3240C
MFC-3340CN

Quick Setup Guide

Before you can use the machine, you must set up the hardware and install the driver. Please read this "Quick Setup Guide" for proper set up and installation instructions.

Step 1



Setting Up the Machine

Step 2

Installing the Driver & Software



Setup is Complete!

For the latest drivers and to find the best solution for your problem or question, access the Brother Solutions Center directly from the driver or go to **http://solutions.brother.com**
Keep this "Quick Setup Guide", User's Guide and supplied CD-ROM in a convenient place for quick and easy reference at all times.

Version A

Warning		**Hint**	**User's Guide**
Indicates warnings that must be observed to prevent possible personal injury.	Indicates cautions that must be observed to use the machine properly or to prevent damage to the machine.	Indicates notes and useful tips to remember when using the machine.	Indicates reference to the User's Guide.

Getting Started

Carton Components





Quick Setup Guide

CD-ROM



User's Guide

Telephone Line Cord



Accessory Order Form



One Touch Label



Test Sheet
(USA only)

Black
(LC41BK)

Magenta
(LC41M)

Yellow
(LC41Y)

Cyan
(LC41C)

Ink Cartridges

Carton components may differ from one country to another.
Save all packing materials and the carton.

If you are connecting the machine via USB:

- *The interface cable is not a standard accessory. Please purchase an appropriate USB 2.0 interface cable.*
- *Please make sure you use a USB 2.0 interface cable that is no longer than 6 feet long (2 meters).*
- *Your MFC has a USB 2.0 Full-Speed interface. This interface is compatible with USB 2.0 Hi-Speed; however, the maximum data transfer rate will be 12 Mbits/s. The MFC can also be connected to a computer that has a USB 1.1 interface.*
- *Most of the illustrations in this Quick Setup Guide show the MFC-3240C.*

Control Panel

(For MFC-3240C)



1. One Touch keys	**5**. Stop/Exit key	**9**. Mode keys
2. Shift	**6**. Start keys	**10**. Liquid Crystal Display (LCD)
3. Fax and telephone keys	**7**. On/Off key	**11**. Copy keys
4. Dial Pad	**8**. Navigation keys	**12**. Print key

For the details of the control panel, see "Control panel overview" in Chapter 1 of the User's Guide.

(For MFC-3340CN)



1. One Touch keys	**6**. Stop/Exit key	**11**. Liquid Crystal Display (LCD)
2. Shift	**7**. Start keys	**12**. Copy keys
3. Photo key	**8**. On/Off key	**13**. Print key
4. Fax and telephone keys	**9**. Navigation keys	
5. Dial Pad	**10**. Mode keys	

For the details of the control panel, see "Control panel overview" in Chapter 1 of the User's Guide.

Table of Contents

Step 1 Setting Up the Machine

1. Removing the Protective Parts 4
2. Loading Paper 4
3. Installing the Phone Line and Power Cord 5
4. Installing the Ink Cartridges 6
5. Print Quality Check 8
6. Setting the Date and Time 9
7. Setting Your Station ID 9
8. Selecting a Receive Mode 10
9. Selecting Your Language (Canada only) 10
10. Sending in the Product Registration and Test Sheet (USA only) 11

Step 2 Installing the Driver & Software

Windows®

Supplied CD-ROM "MFL-Pro Suite" 12

For USB Interface Cable Users

■ For Windows® 98/98SE/Me/2000 Professional/XP 14

For Network Interface Cable Users (MFC-3340CN only)

■ For Windows® 98/98SE/Me/2000 Professional/XP 17

Macintosh®

For USB Interface Cable Users 20

■ For Mac OS® X 10.2.4 or greater 20

■ For Mac OS® 8.6 to 9.2 23

For Network Interface Cable Users (MFC-3340CN only) 25

■ For Mac OS® X 10.2.4 or greater 25

■ For Mac OS® 8.6 to 9.2 28

■ For Network Users (MFC-3340CN only)

Network User's Guide Chapter Map 30

Restoring the Network Settings to Factory Default 30

Installing the BRAdmin Professional Configuration Utility (Windows® only) 31

Setting your IP Address, Subnet Mask and Gateway using BRAdmin Professional (Windows® only) 32

■ Consumables and Options

Replacement Consumables 33

Option 33

Step 1 Setting Up the Machine

1 Removing the Protective Parts

1. Remove the protective tape and paper.

DO NOT connect the USB cable. Connecting the USB cable is done when installing the driver.

2 Loading Paper

You can load up to 100 sheets of 20 lb paper.
For more details, see "About paper" in Chapter 1 of the User's Guide.

1. Pull the paper tray completely out of the machine and remove the output paper tray.



2. Press and slide the paper guide to fit the paper width.



3. Pull out the paper support and unfold the paper support flap.



Use the paper support flap for Letter, Legal and A4 size paper.

4. Fan the stack of paper well to avoid paper jams and mis-feeds.



5. Gently insert the paper into the paper tray print side down and top edge first.
Check that the paper is flat in the tray and below the maximum paper mark.



- *Make sure the paper side guides touch the sides of the paper.*
- *Be careful that you do not push the paper in too far; it may lift at the back of the tray and cause paper feed problems.*

6. Put the output paper tray back on and push the paper tray firmly back into the machine.



3 Installing the Phone Line and Power Cord

1 Connect the power cord.



2 Connect the telephone line cord.
Connect one end of the telephone line cord to the jack on the MFC marked **LINE** and the other end to a modular wall jack.



DO NOT connect the USB cable yet.

Warning

- *The MFC must be connected to a grounded/ earthed plug.*
- *Since the MFC is grounded through the power outlet, you can protect yourself from potentially hazardous electrical conditions on the telephone network by keeping the power switched on when you connect the MFC to a telephone line. Similarly, you can protect yourself when you want to move your MFC by disconnecting the telephone line first and then the power cord.*

If you are sharing one phone line with an external telephone, connect it as shown below.



If you are sharing one phone line with an external telephone answering machine, connect it as shown below.

Please set the Receive Mode to "External TAD" if you have an external answering machine. For more details, see "Connecting an external device to your MFC" in the Appendix of the User's Guide.



4 Installing the Ink Cartridges

Warning

If ink gets in your eyes wash them with water immediately, and if irritation occurs consult a doctor.

1. Make sure that the power is turned on. The LCD shows:

   No Cartridge

2. Open the top cover.



3. Remove the protective parts.



Do not throw away the protective parts. You will need them when you transport the machine.

4. Take out the ink cartridge.



5. Carefully remove the bottom cap.

DO NOT touch the area shown in the illustration below.



If the cartridge cover comes off when you open the bag the cartridge will not be damaged.

Keep the ink cartridge in an upright position when you insert it into the slot.



6 Press firmly down on the ink cartridge until the hook snaps over it, taking care to match the slot color (A) with the cartridge color (B), as shown in the diagram below.



7 Close the top cover.

If `Install` *shows on the LCD after you install the ink cartridges, check to make sure the ink cartridges are installed correctly.*



The machine will clean the ink tube system for use for the first time. This process will occur only once, the first time ink cartridges are installed. The cleaning process will last approximately four minutes.

The LCD shows:

Preparing System
Approx 4 Minutes

- **DO NOT remove ink cartridges if you do not need to replace them. If you do so, it may reduce the ink quantity and the machine will not know the quantity of ink left in the cartridge.**
- **DO NOT shake the ink cartridges. If ink stains your body or clothing, wash with soap or detergent immediately.**
- **DO NOT insert and remove the cartridges repeatedly. If you do so, the ink may seep out of the cartridge.**
- **DO NOT dismantle or tamper with the ink cartridge, this can cause the ink to leak out of the cartridge.**
- **Brother strongly recommends that you do not refill the ink cartridges provided with your machine. We also strongly recommend that you continue to use only Genuine Brother Brand replacement ink cartridges. Using or attempting to use potentially incompatible inks and/or cartridges in your machine may cause damage to the machine itself and/or it may result in unsatisfactory print quality. Our warranty coverage does not apply to any problem that was caused by the use of unauthorized third party ink and/or cartridges. To protect your investment and guarantee your print quality please continue to replace consumed ink cartridges with only Genuine Brother Branded Supplies.**

- *If you mix the colors by installing an ink cartridge in the wrong position, you must clean the print head by running several cleaning cycles after correcting the cartridge installation. (See "Cleaning the print head" in chapter 12 Troubleshooting and Routine Maintenance of the User's Guide.)*
- *Once you open an ink cartridge, install it in the machine and use it up within six months of installation. Use unopened ink cartridges by the expiration date written on the cartridge package.*

5 Print Quality Check

1. After the cleaning cycle is finished, the LCD shows:

Set Paper and
Press Start

2. Make sure the paper is loaded in the paper tray.
   Press **Color Start**.
   The machine starts printing the PRINT QUALITY CHECK SHEET (only during initial ink cartridge installation).

3. Check the quality of the four color blocks formed by the short lines printed on the sheet.
   (BLACK/ CYAN/ YELLOW/ MAGENTA)



Avoid touching the printed surface of the paper immediately after printing, the surface may not be completely dry and may stain your fingers.

4. The LCD shows:

Is Quality OK?
1.Yes 2.No

5. If all lines are clear and visible, press **1** on the dial pad to finish the quality check.
   ---OR---
   If you can see missing short lines, press **2** on the dial pad and go to 6.

OK

Poor



6. The LCD asks you if the print quality is OK for black and color. Press **1** or **2** on the dial pad.

Black OK?
1.Yes 2.No

After making your selection **1** (Yes) or **2** (No) for both black and color, the LCD shows:

Start Cleaning?
1.Yes 2.No

Press **1** (Yes), the machine will then start cleaning the colors.

After cleaning is finished, press **Color Start**. The machine starts printing the PRINT QUALITY CHECK SHEET again and goes back to step 3.

6 Setting the Date and Time

1. Press **Menu/Set**.
2. Press **0**.
3. Press **2**.
4. Enter the last two digits of the year on the dial pad, and then press **Menu/Set**.

   `Year:2004`

   (e.g. Enter **0 4** for 2004.)
5. Enter the two digits for the month on the dial pad, and then press **Menu/Set**.

   `Month:03`

   (e.g. Enter **0 3** for March.)
6. Enter the two digits for the day on the dial pad, and then press **Menu/Set**.

   `Day:01`

   (e.g. Enter **0 1**.)
7. Enter the time in 24-hour format on the dial pad, and then press **Menu/Set**.

   `Time:15:25`

   (e.g. Enter **1 5**, **2 5** for 3:25 P.M.)
8. Press **Stop/Exit**.

*If you want to repeat input, press **Stop/Exit** to start from Step 1.*

7 Setting Your Station ID

You should store your name and fax number to be printed on all fax pages that you send.

1. Press **Menu/Set**.
2. Press **0**.
3. Press **3**.
4. Enter your fax number (up to 20 digits) on the dial pad, and then press **Menu/Set**.

   `Fax:_`
5. Use the dial pad to enter your name (up to 20 characters), and then press **Menu/Set**.

   `Name:_`

- *Refer to the following chart for entering your name.*
- *If you need to enter 2 or more characters in a row from the same key, use the navigation key to move the cursor to the right.*

Press key	One time	Two times	Three times	Four times
2	A	B	C	2
3	D	E	F	3
4	G	H	I	4
5	J	K	L	5
6	M	N	O	6
7	P	Q	R	S
8	T	U	V	8
9	W	X	Y	Z

For more details, see "Setting the Station ID" in Chapter 2 of the User's Guide.

6. Press **Stop/Exit**.

*If you want to repeat input, press **Stop/Exit** to start from Step 1.*

8 Selecting a Receive Mode

There are four possible receive modes: Fax Only, Fax/Tel, Manual and External TAD.



1. Press **Menu/Set**.
2. Press **0**.
3. Press **1**.
4. Press ▲ or ▼ to select the mode.
5. Press **Menu/Set**.
6. Press **Stop/Exit**.

For more details, see "Setup Receive" in Chapter 4 of the User's Guide.

9 Selecting Your Language (Canada only)

1. Press **Menu/Set**.
2. Press **0**.
3. Press **0**.
4. Select your language (English or French) by using ▲ or ▼, and then press **Menu/Set**.

   Language:English
5. Press **Stop/Exit**.

10 Sending in the Product Registration and Test Sheet (USA only)

Continue to Step 2, Installing the Driver & Software

1. Fill out the Product Registration and Test Sheet.



2. Open the document tray (①) and pull out the extension (②) and then open the document support (③).



3. Place the sheet face down in the Automatic Document Feeder.



Make sure (Fax) is illuminated in Green.

4. Enter the toll-free fax number: 1-877-268-9575.

5. Press **Black Start**.

You will receive a confirmation fax of your Product Registration.

You can also register your product online using the On-Line Registration link from the installation CD-ROM or go to http://www.brother.com/registration

Supplied CD-ROM “MFL-Pro Suite”

The CD-ROM includes the following items:

Windows®



MFL-Pro Suite includes Printer Driver, Scanner Driver, ScanSoft® PaperPort® 9.0SE, ScanSoft® OmniPage® and True Type® fonts. PaperPort® 9.0SE is a document management application for viewing scanned documents. ScanSoft® OmniPage®, which is integrated into PaperPort® 9.0SE, is an OCR application that converts an image into text and inserts it into your default word processor.

Install MFL-Pro Suite
You can install the MFL-Pro Suite software and multifunction drivers.

Install Optional Applications
You can install additional MFL-Pro Suite software utilities.

Documentation1*
View the User’s Guide and other documentation in PDF format (Viewer included).

On-Line Registration
You will be pointed to the Brother Product Registration Web page for quick registration of your machine.

Brother Support
View contact information for Brother Customer Service and how to locate a Brother Authorized Service Center.

Repair MFL-Pro Suite
If you experience errors while installing the MFL-Pro Suite you can use this function to automatically repair and re-install the software.

Macintosh®

Start Here
You can install the printer driver, scanner driver and Presto!® PageManager® for Mac OS® 8.6 - 9.2.

Start Here OSX
You can install the printer driver, scanner driver, remote setup program and Presto!® PageManager® for Mac OS® 10.2.4 or greater.

Readme!
You can get important information and troubleshooting tips.

Documentation1*
View the User’s Guide and other documentation in PDF format.

Brother Solutions Center
You can access the Brother Solutions Center which is a Web site offering information about your Brother product including FAQs, User’s Guides, Driver updates and Tips for using your machine.

On-Line Registration
You will be pointed to the Brother Product Registration Web Page for quick registration of your machine.

**1 The User’s Guide on the CD-ROM includes the Software and Network User’s Guide for features available when connected to a computer (e.g. Printing and Scanning).*

Step 2 Installing the Driver & Software

Follow the instructions on this page for your operating system and interface cable.

Windows®

For USB Interface Cable Users
■ Windows® 98/98SE/Me/2000 Professional/XP ... Go to page 14

For Network Interface Cable Users (MFC-3340CN only)
■ Windows® 98/98SE/Me/2000 Professional/XP ... Go to page 17

Macintosh®

For USB Interface Cable Users
■ Mac OS® X 10.2.4 or greater..... Go to page 20

For USB Interface Cable Users
■ Mac OS® 8.6 to 9.2..... Go to page 23

For Network Interface Cable Users (MFC-3340CN only)
■ Mac OS® X 10.2.4 or greater..... Go to page 25
■ Mac OS® 8.6 to 9.2..... Go to page 28

For Network Users ..... Go to page 30
(MFC-3340CN only)

Step 2 Installing the Driver & Software

For USB Interface Cable Users (For Windows® 98/98SE/Me/2000 Professional/XP)

Make sure that you have completed the instructions from Step 1 "Setting Up the Machine" on pages 4 - 11.

If you are using Windows® 2000 Professional (MFC-3340CN only):

To access the PhotoCapture Center™ features from your PC you may have to install a Windows® 2000 update first.

The Windows® 2000 update is included with the MFL-Pro Suite installer.
To install the update, follow the steps below:
1. Follow the installation steps from 1 to 4.
2. Click **OK** to start installation of the update.
3. When instructed, click **OK** to restart your PC.
4. After the PC restarts, the installation of MFL-Pro Suite will automatically continue.

- *If the installation does not continue automatically, please open the MFL-Pro Suite installer menu again by ejecting then reinserting the CD-ROM disc or double-click the **setup.exe** program from the root directory, and continue from Step 4 to install the MFL-Pro Suite.*
- *Make sure there are no media cards inserted into the media drive of the machine.*
- *Brother recommends you connect the machine directly to your computer.*
- *Please close any applications running before installing MFL-Pro Suite.*

1 Disconnect the machine from the AC outlet and from your computer, if you have already connected an interface cable.



2 Turn on your computer.
(For Windows® 2000 Professional/XP, you must be logged on as the administrator.)

3 Insert the supplied CD-ROM into your CD-ROM drive. If the model name screen appears, select your machine. If the language screen appears, select your language.

4 The CD-ROM main menu will appear. Click **Install MFL-Pro Suite**.



*If this window does not appear, use Windows® Explorer to run the **setup.exe** program from the root directory of the Brother CD-ROM.*

(MFC-3340CN only)
*If you see the following screen, click **OK** to install the Windows® updates. After the updates are installed, your PC may restart. Then the installation will automatically continue.*



*If the installation does not continue automatically, please open the main menu again by ejecting then reinserting the CD-ROM disc or double-click the **setup.exe** program from the root directory, and continue from Step 4 to install the MFL-Pro Suite.*

5 After reading and accepting the ScanSoft® PaperPort® 9.0SE License Agreement, click **Yes**.



6 The installation of PaperPort® 9.0SE will automatically start and is followed by the installation of MFL-Pro Suite.

7 When the Brother MFL-Pro Suite Software License Agreement window appears, click **Yes**, if you agree to the Software Licence Agreement.



8 Select **Local Connection**, and then click **Next**.
The installation will continue.



9 When this screen appears, connect the USB interface cable to your PC, and then connect it to the machine.



To connect the USB cable to the machine:

1. Open the top cover to its open position.
2. Insert the USB cable into the USB socket, marked with a symbol. You will find the USB socket above and to the left of the ink cartridge slots, as shown below.



3. Carefully route the USB cable through the trench and out the back of the machine as shown below.



Warning

Ensure that the cable does not restrict the cover from closing, or an error may occur.

DO NOT connect the machine to a USB port on a keyboard or a non powered USB hub.

Continued...

For USB Interface Cable Users (For Windows® 98/98SE/Me/2000 Professional/XP)

10 Gently close the top cover.

11 Turn on the machine by plugging in the power cord.



It will take a few seconds for the installation screens to appear.
The installation of the Brother drivers will automatically start. The installation screens appear one after another, please wait for a while.

12 When the Brother and ScanSoft on-line Registration screen is displayed, make your selection and follow the on-screen instructions.



13 Click **Finish** to restart your computer.



14 After restarting the computer, the Installation Diagnostics will run automatically and the installation results window will be shown.

*If the installation is unsuccessful try installing again using the **Repair MFL-Pro Suite** option from the main menu. Select **Repair MFL-Pro Suite** and follow the instructions on the screen.*

OK! **The MFL-Pro Suite, Brother Printer driver and Scanner driver have been installed and the installation is now complete.**

For Network Interface Cable Users (MFC-3340CN only) (Windows® 98/98SE/Me/2000 Professional/XP)

Make sure that you have completed the instructions from Step 1 "Setting Up the Machine" on pages 4 - 11.

Before installation, if you are using Personal Firewall software, disable it. Once you are sure that you can print, re-start your Personal Firewall software.

1 Connect the network cable to the machine, and then connect it to a free port on your hub.

To connect the network interface cable to the machine:

1. Open the top cover to its open position.
2. Insert the network cable into the LAN socket, marked with a symbol. You will find the LAN socket above and to the left of the ink cartridge slots, as shown below.



3. Carefully route the network cable through the trench and out the back of the machine as shown below.



Warning

Ensure that the cable does not restrict the cover from closing, or an error may occur.

In case of using both USB and LAN cables, route both cables through the trench.

2 Gently close the top cover.

3 Turn on the machine by plugging in the power cord.



4 Turn on your computer.
(For Windows® 2000 Professional/XP, you must be logged on as the administrator.)

5 Insert the supplied CD-ROM into your CD-ROM drive. If the model name screen appears, select your machine. If the language screen appears, select your language.

6 The CD-ROM main menu will appear. Click **Install MFL-Pro Suite**.

*If this window does not appear, use Windows® Explorer to run the **setup.exe** program from the root directory of the Brother CD-ROM.*

Continued...

For Network Interface Cable Users (MFC-3340CN only) (For Windows® 98/98SE/Me/2000 Professional/XP)

*If you see the following screen, click **OK** to install the Windows® updates. After the updates are installed your PC may restart. Then the installation will automatically continue.*



*If the installation does not continue automatically, please open the main menu again by ejecting then reinserting the CD-ROM disc or double-click the **setup.exe** program from the root directory, and continue from Step 6 to install the MFL-Pro Suite.*

7 After reading and accepting the ScanSoft® PaperPort® 9.0SE License Agreement, click **Yes**.



8 The installation of PaperPort® 9.0SE will automatically start and is followed by the installation of MFL-Pro Suite.

9 When the Brother MFL-Pro Suite Software License Agreement window appears, click **Yes**, if you agree to the Software Licence Agreement.



10 Select **Network Connection**, and then click **Next**.



11 The installation of the Brother drivers will automatically start. The installation screens appear one after another, please wait for a while.

12 If the machine is configured for your network, select the machine from the list, and then click **Next**.

This window will not appear if there is only one machine connected on the network, it will be selected automatically.

If the machine is not yet configured for use on your network, the **Configure IP Address** window will appear. Enter the IP address information appropriate to your network by following the on-screen instructions.

13 When the Brother and ScanSoft on-line Registration screen is displayed, make your selection and follow the on-screen instructions.



14 Click **Finish** to restart your computer.



15 After restarting the computer, the Installation Diagnostics will run automatically and the installation results window will be shown.

*For network installations the **Repair MFL-Pro Suite** selection from the main menu is not supported.*

OK! **The MFL-Pro Suite, Brother Network Printer driver, Network Scanner driver and Network PhotoCapture Center™ have been installed and the installation is now complete.**

For USB Interface Cable Users

For Mac OS® X 10.2.4 or greater

Make sure that you have completed the instructions from Step 1 "Setting Up the Machine" on pages 4 - 11.

For Mac OS® X 10.2.0 to 10.2.3 user, please upgrade to Mac OS® X 10.2.4 or greater. (The latest information for Mac OS® X, please visit at: http://solutions.brother.com)

1. Disconnect the machine from the power outlet and from the Macintosh®, if you have already connected an interface cable.



2. Turn on your Macintosh®.
3. Insert the supplied CD-ROM into your CD-ROM drive.

4. Double-click the **Start Here OSX** icon to install the printer driver, Scanner driver and Remote Setup program. If the language screen appears, select your language.



5. Click **MFL-Pro Suite** to install.



6. Follow the on-screen instructions, and restart your Macintosh®.
7. After the **DeviceSelector** window appears, connect the USB interface cable to your Macintosh® and then to the machine.

The **DeviceSelector** window will not appear if the USB interface cable has been connected before restarting your Macintosh® or if you are overwriting a previously installed version of the Brother Software. If you encounter this problem continue with the installation skipping step 10 and then see the Software User's Guide Chapter 8 for details on selecting what machine the ControlCenter2.0 will connect with.

To connect the USB cable to the machine:

1. Open the top cover to its open position.
2. Insert the USB cable into the USB socket, marked with a symbol. You will find the USB socket above and to the left of the ink cartridge slots, as shown below.



3. Carefully route the USB cable through the trench and out the back of the machine as shown below.



Warning

Ensure that the cable does not restrict the cover from closing, or an error may occur.

DO NOT connect the machine to a USB port on a keyboard or a non powered USB hub.

8. Gently close the top cover.

9. Turn on the machine by plugging in the power cord.



10. Select **USB** and then click **OK**.

11. Select **Applications** from the **Go** menu.



12. Open the **Utilities** folder.

13. Open the **Print Center** icon.

14. Click **Add**.



Continued...

For USB Interface Cable Users

15 Select **USB**.



16 Select **MFC-XXXX** (XXXX is your model name), and then click **Add**.



17 Select **Quit Printer Setup Utility** from the **Printer Setup Utility** menu.



OK! **The MFL-Pro Suite, Brother Printer driver, Scanner driver and Remote Setup Program have been installed and the installation is now complete.**

18 To install Presto!® PageManager®, click the **Presto! PageManager** icon and follow the on-screen instructions.

You can easily scan, share and organize photos and documents using Presto!® PageManager®.

OK! **Presto!® PageManager® has been installed and the installation is now complete.**

For Mac OS® 8.6 to 9.2

Make sure that you have completed the instructions from Step 1 "Setting Up the Machine" on pages 4 - 11.

1. Disconnect the machine from the power outlet and from the Macintosh®, if you have already connected an interface cable.



2. Turn on your Macintosh®.

3. Insert the supplied CD-ROM into your CD-ROM drive.



4. Double-click the **Start Here** icon to install the printer and scanner drivers. If the language screen appears, select your language.



5. Click **MFL-Pro Suite** to install.



6. Follow the on-screen instructions, and restart your Macintosh®.

7. Connect the USB interface cable to your Macintosh®, and then connect it to the machine.

   To connect the USB cable to the machine:
   1. Open the top cover to its open position.
   2. Insert the USB cable into the USB socket, marked with a ⇐ symbol. You will find the USB socket above and to the left of the ink cartridge slots, as shown below.



   3. Carefully route the USB cable through the trench and out the back of the machine as shown below.



Warning

Ensure that the cable does not restrict the cover from closing, or an error may occur.

DO NOT connect the machine to a USB port on a keyboard or a non powered USB hub.

Continued...

8 Gently close the top cover.

9 Turn on the machine by plugging in the power cord.



10 From the Apple® menu, open the **Chooser**.

11 Click the **Brother Ink** icon.
On the right side of the **Chooser**, select the machine to which you want to print.
Close the **Chooser**.



OK! **The Brother Printer driver and Scanner driver have been installed.**

12 To install Presto!® PageManager®, click the **Presto! PageManager** icon and follow the on-screen instructions.

You can easily scan, share and organize photos and documents using Presto!® PageManager®.

OK! **Presto!® PageManager® has been installed and the installation is now complete.**

For Network Interface Cable Users (MFC-3340CN only)

For Mac OS® X 10.2.4 or greater

Make sure that you have completed the instructions from Step 1 "Setting Up the Machine" on pages 4 - 11.

1. Disconnect the machine from the power outlet and from the Macintosh®, if you have already connected an interface cable.



2. Turn on your Macintosh®.
3. Insert the supplied CD-ROM into your CD-ROM drive.

4. Double-click the **Start Here OSX** icon to install the printer driver and Remote Setup program. If the language screen appears, select your language.



5. Click **MFL-Pro Suite** to install.

6. Follow the on-screen instructions, and restart your Macintosh®.
7. After the **DeviceSelector** window appears, connect the network interface cable to your Macintosh® and then to the machine.

The **DeviceSelector** window will not appear if you have also connected a USB interface cable to the machine before restarting your Macintosh® or if you are overwriting a previously installed version of the Brother Software. If you encounter this problem continue with skipping steps 10 through 12 and then see the Software User's Guide Chapter 8 for details on selecting what machine the ControlCenter2.0 will connect with.

To connect the network interface cable to the machine:

1. Open the top cover to its open position.
2. Insert the network cable into the LAN socket, marked with a symbol. You will find the LAN socket above and to the left of the ink cartridge slots, as shown below.



Continued...

For Network Interface Cable Users (MFC-3340CN only)

3. Carefully route the network cable through the trench and out the back of the machine as shown below.



Warning

Ensure that the cable does not restrict the cover from closing, or an error may occur.

In case of using both USB and LAN cables, route both cables through the trench.

8. Gently close the top cover.

9. Turn on the machine by plugging in the power cord.



10. Select **Network** and then click **OK**.



11. Click **Browse**.

12. Select your model name, and then click **OK**. Then click **OK** again to close the **DeviceSelector**.



13. Select **Applications** from the **Go** menu.



14. Open the **Utilities** folder.

15 Open the **Print Center** icon.

16 Click **Add**.



17 Make the selection shown below.



18 Select **MFC-XXXX** (XXXX is your model name) (**BRN_xxxxxx_P1**), and then click **Add**.



xxxxxx are the last six digits of the Ethernet address.

Network User's Guide Chapter 5 on the CD-ROM.

19 Select **Quit Printer Setup Utility** from the **Printer Setup Utility** menu.





OK! **The setup is now complete.**

Please see Network User's Guide Chapter 5 on the CD-ROM for more information about connecting the MFC to a Macintosh® network.

For Network Interface Cable Users (MFC-3340CN only)

For Mac OS® 8.6 to 9.2

Make sure that you have completed the instructions from Step 1 “Setting Up the Machine” on pages 4 - 11.

1. Disconnect the machine from the power outlet and from the Macintosh®, if you have already connected an interface cable.



2. Turn on your Macintosh®.

3. Insert the supplied CD-ROM into your CD-ROM drive.

4. Double-click the **Start Here** icon to install the printer and scanner drivers. If the language screen appears, select your language.



5. Click **MFL-Pro Suite** to install.



6. Follow the on-screen instructions, and restart your Macintosh®.

7. Connect the network interface cable to the machine, and then connect it to a free port on your hub.

   To connect the network interface cable to the machine:

   1. Open the top cover to its open position.
   2. Insert the network cable into the LAN socket, marked with a symbol. You will find the LAN socket above and to the left of the ink cartridge slots, as shown below.



   3. Carefully route the network cable through the trench and out the back of the machine as shown below.



Warning

Ensure that the cable does not restrict the cover from closing, or an error may occur.

In case of using both USB and LAN cables, route both cables through the trench.

8 Gently close the top cover.

9 Turn on the machine by plugging in the power cord.



10 Open the **Chooser** from the **Apple** menu.

11 Click the **Brother Ink (IP)** icon, and then select **BRN_xxxxxx**.
Close the **Chooser**.



- *xxxxxx are the last six digits of the Ethernet address.*
- *Please see Network User's Guide Chapter 5 on the CD-ROM for more information about connecting the MFC to a Macintosh® network.*

OK! **The setup is now complete.**

For Network Users

This section is for using the machine on a network (MFC-3340CN only).
An administrator should set up the machine using the following steps.

Network User's Guide Chapter Map

Windows®



Macintosh®



Windows® 98/Me	Peer-to-Peer	TCP/IP	Chapter 4	Network Printing from Windows®
Windows® 2000/XP	Peer-to-Peer	TCP/IP	Chapter 4	Network Printing from Windows®
Macintosh®		TCP/IP	Chapter 5	Network Printing from Macintosh®
OS2 Warp Server, LAN Server		TCP/IP	Chapter 4	Network Printing from Windows®

Restoring the Network Settings to Factory Default

To restore all network settings of the internal Print/Scan server to factory default, please follow the steps below.

1. Make sure the machine is not operating, then disconnect all the cables from the machine (except power cable).
2. Press **Menu/Set**, **5**, **0**.
3. Press **1** to select Reset.
4. Press **1** to select Yes.
5. The machine will restart, re-connect cables once this is complete.

Installing the BRAdmin Professional Configuration Utility (Windows® only)

The BRAdmin Professional utility is designed to manage your Brother network connected devices such as network-ready Multifunction devices and/or network-ready printers in a Local Area Network (LAN) environment.
BRAdmin Professional can also be used to manage devices from other manufacturers whose products support SNMP (Simple Network Management Protocol).
For more information on BRAdmin Professional go to http://solutions.brother.com

1. Insert the supplied CD-ROM into your CD-ROM drive. The opening screen will appear automatically.
   Follow the on-screen instructions.

2. Click the **Install Optional Applications** icon on the main menu screen.



3. Click **BRAdmin Professional** and follow the on-screen instructions.



*The default password for the print server is "**access**". You can use BRAdmin Professional to change this password.*

Setting your IP Address, Subnet Mask and Gateway using BRAdmin Professional (Windows® only)

1. Start BRAdmin Professional, and select **TCP/IP**.



2. Select **Search Active Devices** from the **Devices** menu.
BRAdmin will search for new devices automatically.



3. Double-click the new device.



4. Enter the **IP Address**, **Subnet Mask** and **Gateway**, and then click the **OK** button.



5. The address information will be saved to the machine.

*The default password for the print server is "**access**". You can use BRAdmin Professional to change this password..*

Consumables and Options

Replacement Consumables

Ink Cartridge

Black (Standard)	Black (High Yield)	Magenta	Yellow	Cyan
LC41BK	LC41HYBK	LC41M	LC41Y	LC41C
				

Option

The external wireless Print/Scan server (802.11b) is available for Brother MFC's as an option.

External Wireless Print/ Scan Server
NC-2200w
The optional External Wireless Print/Scan Server (NC-2200w) provides wireless network printing and network scanning capabilities.

- *Requires USB 2.0 cable (not included).*
- *Supports Mac OS® X 10.2.4 or greater.*
- *You can assign the scan key to one networked computer only.*

Trademarks

The Brother logo is a registered trademark of Brother Industries, Ltd.
Brother is a registered trademark of Brother Industries, Ltd.
Multi-Function Link is a registered trademark of Brother International Corporation.
© Copyright 2004 Brother Industries, Ltd. All rights reserved.
Windows and Microsoft are registered trademarks of Microsoft in the U.S. and other countries.
Macintosh and True Type are registered trademarks of Apple Computer, Inc.
PaperPort and OmniPage OCR are registered trademarks of ScanSoft, Inc.
Presto! PageManager is a registered trademark of NewSoft Technology Corporation.
Each company whose software title is mentioned in this manual has a Software License Agreement specific to its proprietary programs.
All other brand and product names mentioned in this manual are registered trademarks of their respective companies.

Compilation and Publication

Under the supervision of Brother Industries Ltd., this manual has been compiled and published, covering the latest product descriptions and specifications.
The contents of this manual and the specifications of this product are subject to change without notice.
Brother reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publication.
This product is designed for use in a Professional Environment.

©2004 Brother Industries, Ltd.

USA
LF5691001①