

brother[®]

**LASER PRINTER
SERVICE MANUAL**

MODEL:HL-1260e/1660

CONTENTS

CHAPTER I GENERAL

| | | |
|-----|--|---------------------------|
| 1. | FEATURES | Refer to HL-1260 (P.I-1) |
| 2. | SPECIFICATIONS | I-1 |
| 3. | SAFETY INFORMATION | I-6 |
| 3.1 | Laser Safety (110 - 120V Model only) | I-6 |
| 3.2 | CDRH Regulations (110 - 120V Model only) | I-6 |
| 3.3 | Additional Information | I-7 |
| 4. | PARTS OF THE PRINTER | Refer to HL-1260 (P.I-8) |
| 4.1 | External Views | Refer to HL-1260 (P.I-8) |
| 4.2 | Cross Sectional View | Refer to HL-1260 (P.I-9) |
| 5. | STORAGE AND HANDLING OF EP-ED CARTRIDGES | Refer to HL-1260 (P.I-10) |
| 5.1 | Storage of Sealed EP-ED Cartridges | Refer to HL-1260 (P.I-10) |
| 5.2 | Storage of Unsealed EP-ED Cartridges | Refer to HL-1260 (P.I-10) |

CHAPTER II THEORY OF OPERATION

| | | |
|-------|--|----------------------------|
| 1. | BASIC OPERATIONS | II-1 |
| 1.1 | Mechanical Configuration | Refer to HL-1260 (P.II-1) |
| 1.2 | Main Drive | Refer to HL-1260 (P.II-2) |
| 1.3 | Basic Sequence of Operations | II-1 |
| 2. | LASER/SCANNER SYSTEM | Refer to HL-1260 (P.II-4) |
| 3. | IMAGE FORMATION SYSTEM | Refer to HL-1260 (P.II-5) |
| 3.1 | Outline | Refer to HL-1260 (P.II-5) |
| 3.2 | Printing Process | Refer to HL-1260 (P.II-5) |
| 3.2.1 | Electrostatic latent image formation stage | Refer to HL-1260 (P.II-6) |
| 3.2.2 | Developing stage | Refer to HL-1260 (P.II-8) |
| 3.2.3 | Transfer stage | Refer to HL-1260 (P.II-9) |
| 3.2.4 | Fixing stage | Refer to HL-1260 (P.II-10) |
| 3.2.5 | Drum cleaning stage | Refer to HL-1260 (P.II-10) |
| 3.3 | Operation | Refer to HL-1260 (P.II-11) |
| 4. | PAPER PICK-UP/FEED SYSTEM | II-2 |
| 4.1 | Outline | Refer to HL-1260 (P.II-12) |
| 4.2 | Cassette Feed | II-2 |
| 4.3 | MP Tray Feed | II-3 |
| 4.4 | Paper Jam Detection | II-4 |

CHAPTER III ELECTRICAL SYSTEM

| | | |
|-----|---|-----------------------------|
| 1. | MAIN PCB | III-1 |
| 1.1 | Outline | III-1 |
| 1.2 | Video Controller Circuit | III-2 |
| 1.3 | Engine Controller Circuit | III-6 |
| 2. | PAPER FEED DRIVE CIRCUIT | Refer to HL-1260 (P.III-9) |
| 3. | DISPLAY CIRCUIT | Refer to HL-1260 (P.III-11) |
| 3.1 | Outline | Refer to HL-1260 (P.III-11) |
| 3.2 | Operation | Refer to HL-1260 (P.III-11) |
| 4. | LOW-VOLTAGE POWER SUPPLY ASSY | Refer to HL-1260 (P.III-12) |
| 4.1 | Outline | Refer to HL-1260 (P.III-12) |
| 4.2 | Protection Functions | Refer to HL-1260 (P.III-12) |
| 5. | HIGH-VOLTAGE POWER SUPPLY ASSY | Refer to HL-1260 (P.III-14) |
| 5.1 | Outline | Refer to HL-1260 (P.III-14) |
| 5.2 | Operation of the Components of the High-Voltage Power Supply Assy | Refer to HL-1260 (P.III-14) |

CHAPTER IV MECHANICAL SYSTEM

| | | |
|-------|---|----------------------------|
| | PRINTER DISASSEMBLING PROCEDURE | Refer to HL-1260 (P.IV-2) |
| 1.1 | Configuration | Refer to HL-1260 (P.IV-3) |
| 1.2 | Toner Cartridge Lid | IV-2 |
| 1.3 | Side Cover L | Refer to HL-1260 (P.IV-3) |
| 1.4 | Font Cover Assy | Refer to HL-1260 (P.IV-4) |
| 1.5 | Upper Cover Assy, Rear Cover Assy | Refer to HL-1260 (P.IV-4) |
| 1.5.1 | Upper cover assy, rear cover assy | Refer to HL-1260 (P.IV-4) |
| 1.5.2 | Changeover guide, jam remove cover | Refer to HL-1260 (P.IV-5) |
| 1.6 | Side Cover R | Refer to HL-1260 (P.IV-5) |
| 1.7 | DC Fan Motor | IV-2 |
| 1.8 | Main PCB | IV-3 |
| 1.9 | Control Panel Unit | Refer to HL-1260 (P.IV-8) |
| 1.10 | Scanner Unit | IV-5 |
| 1.11 | Cartridge Stopper Assy | IV-5 |
| 1.12 | Paper Feed Chassis Unit | Refer to HL-1260 (P.IV-10) |
| 1.13 | Separation Pad Assy | Refer to HL-1260 (P.IV-11) |
| 1.14 | MP PE Sub Actuator | Refer to HL-1260 (P.IV-12) |
| 1.15 | P Feed /Size-SW PCB Assy | Refer to HL-1260 (P.IV-12) |
| 1.16 | Size-Switch Spring | Refer to HL-1260 (P.IV-12) |
| 1.17 | Regist Sensor Actuator | Refer to HL-1260 (P.IV-13) |
| 1.18 | MP Paper Detection Actuator | Refer to HL-1260 (P.IV-13) |
| 1.19 | PE Sensor Actuator MP | Refer to HL-1260 (P.IV-13) |
| 1.20 | Tray Sensor Holder | Refer to HL-1260 (P.IV-14) |
| 1.21 | Roller Holder | Refer to HL-1260 (P.IV-14) |
| 1.22 | Paper Pick-up Roller Assy, Bearing | Refer to HL-1260 (P.IV-15) |
| 1.23 | Paper Pick-up Solenoid | Refer to HL-1260 (P.IV-16) |
| 1.24 | Paper Feed Motor Assy | Refer to HL-1260 (P.IV-16) |
| 1.25 | MP Tray Cover | Refer to HL-1260 (P.IV-17) |
| 1.26 | MP Tray Assy | Refer to HL-1260 (P.IV-17) |
| 1.27 | Paper Path Separation Plate, Paper Path Separation Film | Refer to HL-1260 (P.IV-18) |
| 1.28 | Latch | Refer to HL-1260 (P.IV-19) |
| 1.29 | Fixing Unit (for both 120V and 230V, the only difference is the halogen heater) | Refer to HL-1260 (P.IV-19) |
| 1.30 | Transfer Unit | Refer to HL-1260 (P.IV-22) |

| | | |
|--------|--|----------------------------|
| 1.31 | DC Gear Holder Assy | IV-6 |
| 1.31.1 | Scanner Fan Motor | IV-6 |
| 1.32 | PS Switch Wire, Remote Switch | Refer to HL-1260 (P.IV-23) |
| 1.33 | High-Voltage Power Supply PCB Assy | Refer to HL-1260 (P.IV-24) |
| 1.34 | Low-Voltage Power Supply PCB Assy | Refer to HL-1260 (P.IV-24) |
| 1.35 | Toner Cartridge (EP-ED Cartridge) | Refer to HL-1260 (P.IV-25) |
| 1.36 | Paper Tray | IV-7 |

CHAPTER V MAINTENANCE AND SERVICING

| | | |
|----|---|--------------------------|
| 1. | PERIODICAL REPLACEMENT PARTS | Refer to HL-1260 (P.V-1) |
| 2. | CONSUMABLE PARTS STANDARD ENDURANCE TABLE | V-1 |
| 3. | LIST OF STANDARD TOOLS | Refer to HL-1260 (P.V-2) |
| 4. | LIST OF LUBRICANTS AND CLEANERS | Refer to HL-1260 (P.V-3) |

CHAPTER VI TROUBLESHOOTING

| | | |
|-----|--|----------------------------|
| 1. | INTRODUCTION | Refer to HL-1260 (P.VI-1) |
| 1.1 | Initial Check..... | Refer to HL-1260 (P.VI-1) |
| 1.2 | Basic Procedure | Refer to HL-1260 (P.VI-2) |
| 2. | TEST PRINTING AND MECHANICAL CHECK | Refer to HL-1260 (P.VI-2) |
| 2.1 | Test Printing | Refer to HL-1260 (P.VI-2) |
| 3. | IMAGE DEFECTS | Refer to HL-1260 (P.VI-3) |
| 3.1 | Image Defect Examples | Refer to HL-1260 (P.VI-3) |
| 3.2 | Troubleshooting Image Defects | Refer to HL-1260 (P.VI-4) |
| 4. | TROUBLESHOOTING OF MALFUNCTIONS | VI-1 |
| 5. | TROUBLESHOOTING PAPER TRANSPORT PROBLEMS | Refer to HL-1260 (P.VI-19) |
| 5.1 | Paper Jams | Refer to HL-1260 (P.VI-19) |
| 5.2 | Incomplete Paper Feed | Refer to HL-1260 (P.VI-22) |
| 6. | OPERATION | Refer to HL-1260 (P.VI-23) |
| 6.1 | Line Inspection Mode Procedure | Refer to HL-1260 (P.VI-23) |
| 6.2 | DRAM Test | Refer to HL-1260 (P.VI-25) |
| 7. | STATUS MESSAGE LIST | VI-9 |

APPENDICES

| | | |
|-----|--|---------------------------|
| 1. | Engine Block Diagram | A-1 |
| 2. | Paper Feed/Size-SW PCB Circuitry Diagram (1/1) | Refer to HL-1260 (P.A-2) |
| 3. | Main PCB Circuitry Diagram (1/7) | A-2 |
| 4. | Main PCB Circuitry Diagram (2/7) | A-3 |
| 5. | Main PCB Circuitry Diagram (3/7) | A-4 |
| 6. | Main PCB Circuitry Diagram (4/7) | A-5 |
| 7. | Main PCB Circuitry Diagram (5/7) | A-6 |
| 8. | Main PCB Circuitry Diagram (6/7) | A-7 |
| 9. | Main PCB Circuitry Diagram (7/7) | A-8 |
| 10. | Control Panel PCB Circuitry Diagram (1/1) | Refer to HL-1260 (P.A-11) |
| 11. | Scanner LD PCB Circuitry Diagram (1/1) | A-9 |