# brother

# Quick Setup Guide


Read the Product Safety Guide first, then read this Quick Setup Guide for the correct installation procedure.

Not all models are available in all countries. The latest manuals are available at the Brother Solutions




USA/CAN

# Unpack the machine and check the components









**Drum Unit and Toner Cartridge Assembly** (pre-installed)



**Quick Setup Guide** 



**Installation CD-ROM** 



**AC Power Cord** 



**Reference Guide** (only for certain models)

• Manuals in Spanish for this model are available on the Brother Solutions Center. (USA

Los manuales en español de este modelo están disponibles en el Brother Solutions Center. (Solamente en los Estados Unidos): solutions.brother.com/manuals

- The available connection interfaces vary depending on the model.
- You must purchase the correct interface cable for the interface you want to use.

### **USB** cable

Center: solutions.brother.com/manuals.

We recommend using a USB 2.0 cable (Type A/B) that is no more than 6 feet (2 meters) long.

**Network cable** (For HL-L5100DN / HL-L5200DW(T) / HL-L6200DW(T)) Use a straight-through Category 5 (or greater) twisted-pair cable.


### Parallel cable

(For HL-L5000D)


Use the parallel cable provided with the machine.

• The illustrations in this Quick Setup Guide show the HL-L6200DW.


## Remove the packing materials and install the drum unit and toner cartridge assembly



## Load paper in the paper tray



## Connect the power cord and turn on the machine



# Select your language (if needed)

- 1. Press ▼ or ▲ to select [General Setup], and then press OK.
- 2. Press OK to select [Local Language].
- Press ▼ or ▲ to select your language, and then press **OK**.
- 4. Press Cancel.



### Connect your machine and install software

Brother regularly updates firmware to add features and fix identified problems. To check for the latest firmware, visit solutions.brother.com/up1.

### Windows® computer with CD-ROM drive



### NOTE:

If the Brother screen does not appear automatically, click (Start) > Computer (My Computer). (For Windows® 8: click the [Signature] (File Explorer) icon on the taskbar, and then go to Computer (This

Double-click the CD-ROM icon, and then doubleclick start.exe.

Download the full driver and software package from

### ■ For HL-L5000D



Follow the on-screen instructions to continue installation.



For other models Choose your Connection Type:





Follow the on-screen instructions to continue installation.



**Finish** 

Follow the on-screen instructions to continue installation.



If using a wireless network connection: When the Wireless Device Setup screen appears, select Setup without a USB cable (Recommended).

Macintosh/Windows® computer without CD-ROM drive

(Macintosh) solutions.brother.com/mac

(Windows®) solutions.brother.com/windows

the Brother Solutions Center.



When instructed, go to your machine. Press the ( (WiFi) button.



### NOTE:

to continue installation.

Follow the on-screen instructions

· When finished, restart your computer.


• If connection is unsuccessful, see ? Cannot set up your machine? below.

## WiFi Alternate wireless configuration method (Setup Wizard)

Restart your wireless access point/router.




If you cannot find this information, ask your network administrator or wireless access point/router manufacturer.



- a. Press ▲ or ▼ to select the [Network] option, and then press OK.
- b. Press ▲ or ▼ to select the [WLAN] option, and then press **OK**.
- option, and then press **OK**. d. When [WLAN Enable?] appears, press ▲ to select [On].


c. Press ▲ or ▼ to select the [Setup Wizard]



Select the SSID. Enter the Network key.




To use with your computer, follow Step 5 until the Select Machine screen appears, listing all machines in your network.



To use with your mobile device, go to Print using your mobile device (not available for HL-L5000D).

Select your machine.



NOTE:

**Finish** 

vour machine? below.

· When finished, restart your computer. • If connection is unsuccessful, see ? Cannot set up

For Network Users: Important Notice for Network Security

The default Web Based Management password is located on the back of the machine and marked "Pwd". We recommend immediately changing the default password to use network tools/utilities securely and to protect your machine from unauthorized access.

### Print using your mobile device (not available for HL-L5000D)

Before printing from your mobile device, your machine must be configured according to step 5 or River Alternate wireless configuration method (Setup Wizard).



Download "Brother iPrint&Scan" to start using your machine with mobile devices.

solutions.brother.com/ips




AirPrint is available for OS X and iOS users.

For more information, see the AirPrint Guide on your model's Manuals web page.

solutions.brother.com/manuals



### Cannot set up your machine?



### NOTE:

If you repeat these steps and connection is still unsuccessful, please visit the Brother Solutions Center at: http://support.brother.com

