

Read the Product Safety Guide first, then read this Quick Setup Guide for the correct installation procedure.

WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injuries.

NOTE

NOTE specifies the operating environment, conditions for installation, or special conditions of use.




Watch our FAQ Videos for help with setting up your Brother machine.
solutions.brother.com/videos




Visit the Brother support website
support.brother.com

Unpack the machine and check the components

1. Remove the protective tape and film covering the machine.
2. Make sure you have all components shown below.



Starter Ink Cartridges [x4]
• Black
• Yellow
• Cyan
• Magenta



**Quick Setup Guide
Basic User's Guide
Product Safety Guide**



Brother Installation Disc



Telephone Line Cord

WARNING

Plastic bags are used in the packing of your machine. Plastic bags are not toys. To avoid the danger of suffocation, keep these bags away from babies and children, and dispose of them correctly.

NOTE

Manuals in Spanish for this model are available at support.brother.com
Manuales en Español para este modelo están disponibles en support.brother.com
• Save all packing materials and the box in case for any reason you must ship your machine.
• You must purchase the correct interface cable for the interface you want to use (for either a USB or network connection).


USB cable

We recommend using a USB 2.0 cable (Type A/B) that is no more than 6 feet (2 meters) long.


Ethernet (Network) cable

Use a straight-through Category5 (or greater) twisted-pair cable for 10BASE-T or 100BASE-TX Fast Ethernet Network.


1 Load plain Letter/A4 paper




Pull the paper tray completely out of the machine.




Open the output paper tray cover ❶.



Adjust the paper guides.
Fan the paper well and load it in the tray.



Close the output paper tray cover, and then slowly push the tray completely into the machine.




NOTE

Pull out the paper support ❶, and unfold the paper support flap ❷ so that the printed pages do not fall.

2 Connect the telephone line cord


If you are not using your machine as a fax, go to 3



Connect the telephone line cord. Use the jack marked **LINE** and guide the cord out the back of the machine.


NOTE

If you are sharing one telephone line with an external telephone, connect it as shown below. Before you connect the external telephone, remove the white protective cap ❸ from the **EXT.** jack of the machine.



- ❶. Extension telephone
- ❷. External telephone
- ❸. Protective cap


3 Connect the power cord




Connect the power cord. The machine will power on automatically.

NOTE


You can adjust the control panel angle to read the Touchscreen more easily.



4 Install starter ink cartridges



Open the ink cartridge cover, and then remove the orange protective part from the machine.



Follow the Touchscreen instructions to install the ink cartridges. The machine will prepare the ink tube system for printing.

5 Machine Settings

When the machine has finished the initial cleaning process, follow the Touchscreen instructions to configure the machine settings.

- Check print quality
- Set date and time
- View operation tips
- Set Message from Brother
- Print the installation sheet

6 Choose your language (if needed)

1. Press [Settings] > [All Settings] > [Initial Setup] > [Local Language].
2. Press your language.
3. Press .

7 Choose the correct Receive Mode

If you are not using your machine as a fax, go to 9

The correct Receive Mode is determined by the external devices and telephone subscriber services (Voice Mail, Distinctive Ring, etc.) you will be using on the same line as the Brother machine. For more information, see *Receive Modes* in chapter 7 of the *Basic User's Guide*.

1. Press [Settings] > [All Settings] > [Fax] > [Setup Receive] > [Receive Mode].
2. Press your preferred Receive Mode.
3. Press .

8 Set your Station ID

If you are not using your machine as a fax, go to 9

Store your name and fax number so the machine prints it on all outgoing fax pages. For more information, see *Enter Text on Your Brother Machine* in *Appendix* of the *Basic User's Guide*.

1. Press [Settings] > [All Settings] > [Initial Setup] > [Station ID] > [Fax].
2. Enter your fax number (up to 20 digits) on the Touchscreen, and then press [OK].
3. Press [Name].
4. Enter your name (up to 20 characters) using the Touchscreen, and then press [OK].
5. Press .



9 Select a device to connect your machine


Computer



Go to **10** and select one of the following:

- Wireless Network Connection (Wi-Fi®)
- Wired Network Connection (Ethernet)
- Local Connection (USB)


Mobile Device



- If you have a computer connected to a wireless network, go to **10** and select Wireless Network Connection.
- If you have only a mobile device, go to **Alternative wireless setup**.

10 Connect your machine and install software

If you are using a new operating system on your computer, visit support.brother.com for updated driver and software information.



Put the installation disc into your CD/DVD drive, or download the Full Driver & Software Package at:

For Windows®:
solutions.brother.com/windows
For Macintosh:
solutions.brother.com/mac


Then, follow the on-screen instructions.




If the screen says “**No machine found**”, wait for the **Wireless Device Setup** screen to appear.



If prompted, go to your machine's Touchscreen, press **WiFi** and then select [WLAN Assistant].



If the **Select Machine** screen appears, select your machine.




Follow the on-screen instructions.


Finished

For Windows®:
If the Brother screen does not appear automatically, go to **Computer (My Computer/This PC)**. Double-click the CD/DVD-ROM icon, and then double-click **start.exe**.


For Macintosh:
For full driver functionality, we recommend choosing the **CUPS driver**.



When instructed, lift the scanner cover, insert your cable into the correct jack, and guide the cable out the back of the machine. Close the scanner cover, and then connect the cable to your network (for Wired Network Connection) or your computer (for USB Connection).




If the **Select Machine** screen appears, select your machine (This screen does not appear for USB connection).



If you have a mobile device, go to **Mobile device support**.


Can't Connect? Check the following:



Alternative wireless setup


Find your SSID (Network Name) and Network Key (Password) on your wireless access point/router and write them in the table provided below.

SSID (Network Name)	
Network Key (Password)	



If you cannot find this information, ask your network administrator or wireless access point/router manufacturer.

Go to your machine, and press **WiFi** > [Setup Wizard] > [Yes].



Select the SSID (Network Name) for your access point/router and enter the Network Key (Password).

When the wireless setup is successful, the Touchscreen displays [Connected].

If setup is not successful, restart your machine and your wireless access point/router, and repeat **Alternative wireless setup**.

For Computer

Go to **10** to install software.


For Mobile Device

Go to **Mobile device support**.

Even if you do not have a wireless access point/router, you can connect your device and your machine directly. See the Additional Wireless Support at solutions.brother.com/wireless-support.



Mobile device support



You can print from and scan to your mobile devices using our free application “Brother iPrint&Scan”.

Download and install the application from solutions.brother.com/ips.



You can print from and scan to your mobile device via many features.

For more information on AirPrint, Google Cloud Print™, and Wi-Fi Direct®, see the *Online User's Guide*. For Mopria™ and Brother Print Service Plugin, visit Google Play™ and install them on your Android™ device.



Brother SupportCenter is a mobile app that provides the latest support information for your Brother product. Visit the App Store or Google Play™ to download.



Additional Wireless Support: solutions.brother.com/wireless-support

For FAQs, Troubleshooting, and to download software and manuals, visit support.brother.com.